



TEXRECO S

WALL COVERING

Technical Data Sheet

Revised: 01/10/2018

DESCRIPTION

Starch paste ready-to-use adhesive for all types of wallpaper. It can also be used in combination with all ACM starch-based products.

Ideal for commercial and contract wall coverings.

- + Exceptional adhesive strength
- + Does not stain
- + Suitable for non-absorbent substrates
- + Low C.O.V (Volatile Organic Compounds)
- + antibacterial and anti-mold properties

Suitable for:

- paper backed vinyl wallpapers and non-woven wallpapers
- contract wall coverings, ideal height: from 53 cm to 160 cm
- non-woven wall coverings
- fiberglass wall coverings

SURFACE PREPARATION

All surfaces must be dry, absorbent, (in this specific case also non-absorbent), strong, free of dust or paints or oils. Any cracks or holes in the wall must be covered with our extra-light GLASTER and in case of imperfections shaved with a normal stucco plaster.

We always recommend the use of our PRIMER AC fixative for consolidation and cleaning.

We recommend using our PRIMER SP (specific for wet walls with fungi and mold) in case of rising damp or too humid.

PREPARATION OF ADHESIVE

TEXRECO S is a ready-to-use product however when necessary, dilute it with clean water up to a maximum of 5%.

APPLICATION

Apply the adhesive in a single coat with a brush, roller, spatula or automatic (pasting machine).

BRUSH - Apply the adhesive on the back of the wall covering evenly. Fold the sheet back on itself and wait 10-20 minutes depending on the ambient temperatures. Proceed following the application of the sheet. Video tutorial: <https://www.youtube.com/watch?v=j7zO9ekpbRg>

ROLLER - Apply the product directly on the wall with roll short wool for about 10/15 m². Proceed accordingly to the application of the wall covering. Video tutorial: <https://www.youtube.com/watch?v=2p-pteh2B1Y>

SPATULA - Apply undiluted with a notched trowel No. 1 directly on the wall. Then proceed to the drafting of the sheets. Video tutorial: <https://www.youtube.com/watch?v=316ytuK36rA>

CONSUMPTION

200-300 g/m²

CLEANING

Clean possible spills with a damp sponge. THE PRODUCT DOES NOT STAIN

CONTRAINDICATIONS

TEXRECO S is not suitable on humid walls with mold or on surfaces not perfectly prepared. Spillage of the adhesive should be removed immediately.

PACKAGES

Bucket 5 Kg	code 10004-S
Bucket 10 Kg	code 10005-S
Bucket 15 Kg	code 10006-S

STORAGE

The product is guaranteed for 24 months from the date of production. Preserve from frost. (+ 5 °C + 40 °C)

TECHNICAL DATA

base:	starch
physical appearance:	white cream
pH:	6.5
viscosity:	50,000 to 60,000 cps
C.O.V.:	zero (0 g / l)
percentage of solid:	about 45%
customs code:	3506 9190
application temperature:	+ 5 °C + 40 °C
waiting time:	0 - 10 minutes
open time:	20 - 30 minutes
setting time:	48 hours
non flammable	

FINAL PROVISIONS

Keep out of the reach of children and pets. Discharge the waste in special containers for building materials.



A.C.M. Sas di Danese R. & C. | Via XXV Aprile, 62 | 20010 Bareggio /MI
PHONE +39 02 903 611 48 | laboratorio@acm-italy.com | www.acm-italy.com