



# TEXRECO TDV

## WALL COVERING

Technical Data Sheet

Revised: 01/10/2018

### **DESCRIPTION**

Starch paste ready-to-use adhesive for all types of wallpapers. Specific for applications of fiberglass wall covering.

It can also be used in combination with all ACM starch-based products.

Ideal for commercial and contract wall coverings.

- + Good adhesive strength
- + Does not stain
- + High yield
- + Low C.O.V (Volatile Organic Compounds)
- + Antibacterial and anti-mold properties

Suitable for:

- paper-backed vinyl wallpapers with or non-woven fabric wallpapers
- non-woven paintable upholstery
- expanded wall coverings
- non-woven wall coverings
- fiberglass wall covering

### **SURFACE PREPARATION**

All surfaces must be dry, absorbent, strong, free of dust or paints or oils. Any cracks or holes in the wall must be covered with our extra-light GLASTER and in case of imperfections shaved with a normal stucco plaster.

We always recommend the use of our PRIMER AC fixative for consolidation and cleaning.

We recommend using our PRIMER SP (specific for wet walls with fungi and mold) in case of rising damp or too humid.

### **PREPARATION OF ADHESIVE**

TEXRECO TDV is a ready-to-use product however when necessary, dilute it with clean water up to a maximum of 5%.

### **APPLICATION**

Apply the adhesive in a single coat with a brush, roller, spatula.

**BRUSH** - Apply the adhesive on the back of the wall covering evenly. Fold the sheet back on itself and wait 10-20 minutes depending on the ambient temperatures. Proceed following the application of the sheet. Video tutorial: <https://www.youtube.com/watch?v=j7zO9ekpbRg>

**ROLLER** - Apply the product directly on the wall with a short wool roll for about 10/15 m<sup>2</sup>. Proceed accordingly to the application of the wall covering. Video tutorial: <https://www.youtube.com/watch?v=2p-pteh2BIY>

**SPATULA** - Apply pure adhesive Texreco TDV with a notched trowel No. 1 directly on the wall. Then proceed following the drafting of the sheets. Video tutorial: <https://www.youtube.com/watch?v=316ytuK36rA>

**MACHINE** - Dilute the adhesive TEXRECO TDV with water up to 5/10% before using the machine.

### **CONSUMPTION**

100 to 180 g/m<sup>2</sup>

### **CLEANING**

Clean possible spills with a damp sponge. THE PRODUCT DOES NOT STAIN

### **CONTRAINDICATIONS**

Do not use the glue on non-absorbent substrates, do not lay on damp walls, with mold or on surfaces not perfectly prepared. Spillage of the adhesive should be removed immediately.

### **PACKAGES**

5 Kg bucket  
10 Kg bucket  
15 Kg bucket

cod. 10004-TDV  
cod. 10005-TDV  
cod. 10006-TDV

### **STORAGE**

The product is guaranteed for 24 months from the date of production. Preserve from frost. (+ 5 °C + 40 °C)

### **TECHNICAL DATA**

base:	starch
physical appearance:	white cream
pH:	6.5
viscosity:	50,000 to 60,000 cps
C.O.V.:	<0.55 g / l
percentage of solid %:	about 25%
customs code:	3506 9190
application temperature:	+ 5 °C + 40 °C
waiting time:	0 - 10 minutes
open time:	20 - 30 minutes
setting time:	48 hours
non flammable	

### **FINAL PROVISIONS**

Keep out of the reach of children and pets. Discharge the waste in special containers for building materials.



A.C.M. Sas di Danese R. & C. | Via XXV Aprile, 62 | 20010 Bareggio /MI  
PHONE +39 02 903 611 48 | [laboratorio@acm-italy.com](mailto:laboratorio@acm-italy.com) | [www.acm-italy.com](http://www.acm-italy.com)