



VK-P

BUILDING PRODUCTS

Technical Data Sheet

Revised: 04/2021

DESCRIPTION

Water-based acrylic Adhesive, for polystyrene, polyurethane base-boards and tiles.
Suction cup effect, strong initial tack.

- + No highly flammable solvents
- + Free labeling EC
- + Paintable

Suitable for:

- skirting wood, PVC, ceramics
- tiles and ceramic mural
- panels frames and polystyrene/ polyurethane rosettes
- cork and therm-acoustic materials
- nails not required
- strong suction cup effect

SURFACE PREPARATION

All surfaces must be dry, absorbent, strong, free of dust or paints or oils. Any cracks must be sealed with our 2-component epoxy adhesive Epoxy.

PREPARATION

Before proceeding with the laying of the covering it is recommended to take it at the construction site the day before in order to allow an adaptation to the environment temperature.

Lay the covering by following the instructions given by the manufacturer. Unroll or simply unpack the flooring to be laid in order to decrease tensions and folds.

PREPARATION OF ADHESIVE

The adhesive is ready for use.

APPLICATION

Apply the product all over the contact surface

CONSUMPTION

About 15 linear meters per cartridge.
100-300 g/m² when applied by trowels.

CLEANING

Clean the equipment with fresh water, immediately after use.

CONTRAINDICATIONS

- + Do not use at temperatures below + 3 °C
- + Application is recommended between 10 °C and + 35 °C

PACKAGES

700 g jar (12 pcs pack)	code 30053
700 g jar (24 pcs pack)	code 30053-24
Bucket 6 kg	code 30054
Bucket 13 kg	code 30055
Bucket 20 kg	code 30108-20

STORAGE

The product is guaranteed for 24 months from the date of production.

TECHNICAL DATA

base:	acrylic
appearance:	extra color white or colored on request
percentage of solid:	80%
customs code:	3506 9100
application temperature:	+ 10 °C + 35 °C
waiting time:	none
open time:	30-40 minutes
setting time:	48/72 hours

FINAL PROVISIONS

Keep out of the reach of children and animals. Discharge the waste in special containers for building materials.



ACM Italy S.r.l. | Via Enrico Mattei, 8 | 20010 Casorezzo /MI
PHONE +39 02 903 611 48 | laboratorio@acm-italy.com | www.acm-italy.com